

CP4-HW-OT



**Programmable RF Cylinder
Thermostat & Receiver**

Installation and Operation Guide

Table of contents

RFRP-HW-OT Room Thermostat	
Installation Instructions	5
Factory Default Settings	6
Frost Protection	6
Specifications	7
How your cylinder thermostat works	8
Mounting of temperature sensor	9
Mounting & Installation	10
RF1A-OT Wireless Receiver	
Installation Instructions	13
Specifications & Wiring	14
Mounting & Installation	15
RFRP-HW-OT Room Thermostat	
Operating Instructions	17
LCD Symbol Description	18
Button Description	19
Resetting the thermostat	20
Keypad lock and unlock	20
Setting the date, time and programming mode	21
Factory Program Setting	22

Programming Modes	23
Adjust the program setting in 5/2 Day mode	24
Copy Function	25
Permanent Override	26
Boost Function	27
Holiday Function	28
Backlight mode selection	29
Battery low warning	29
Replacing the batteries	30
Installer menu	31
PO 1 Operating Mode	32
Normal	32
PO 3 Hysteresis H ON and H OFF	32
PO 4 Calibrate the thermostat	33
PO 5 Frost Protection	33
Exit	33

Table of contents (Continued)

RFRP-HW-OT Room Thermostat (Continued)	
Installer menu - OpenTherm®	
PO 7 OpenTherm® Information	34
Exit	35
Controlling an OpenTherm® Boiler with multiple CP4-OT / CP4-HW-OT	36
System Architecture	40
RF1A-OT Wireless Receiver	
Operating Instructions	42
Button / LED Description	43
LED Description	44
To connect the RFRP-HW-OT thermostat to an RF1A-OT receiver	45
To disconnect the RFRP-HW-OT thermostat to an RF1A-OT receiver	46



RFRP-HW-OT Cylinder Thermostat
Installation Instructions

Factory Default Settings



Temperature indicator:	°C
Switching differential:	5°C
In built frost protection:	5°C - Not adjustable
Clock:	24 hours
Keypad lock:	OFF
Operating mode:	5/2 day
Default temperature setpoint:	60°C

Frost Protection



5°C

Frost protection is built into this thermostat.

It is pre fixed at 5°C and is not adjustable.

It will only be activated when the thermostat is in the OFF mode and the cylinder temperature falls below 5°C.

Specifications

Power supply:	2 x AA Alkaline Batteries
Power consumption:	2 mW
Battery replacement:	Once a year
Temp. control range:	5 ... 90°C
Ambient temperature:	0 ... 45°C
Dimensions:	130 x 99 x 25mm
Temperature sensor:	NTC 100K Ohm @ 25°C
External sensor length:	1950mm ± 80mm
Temperature indication:	°C
Switching differential:	5°C
Frost protection:	Only operational in OFF mode
Pollution degree:	Pollution degree 2

How your cylinder thermostat works

When the thermostat is in the AUTO mode, it will operate according to the times that have been programmed. The user can select from 6 different programs per day - each with a time and a status of ON or OFF.

When program is scheduled to be ON, it will remain on until the next OFF program.

During this time the thermostat will remain ON until the temperature setpoint is reached.

There is only one temperature setpoint which is applied to all programs. The default temperature setpoint is 60°C.

60°C is the temperature level required in order to prevent the build up of legionella bacteria.

Mounting of temperature sensor

ON CYLINDER: To ensure accurate control of your cylinder, the temperature sensor should be mounted on the bottom 1/3 of the cylinder. It is essential that the sensing element is in direct contact with the cylinder and that there is no insulation between it and the cylinder. The temperature sensor can be fixed to the cylinder using the provided foil tape.

ON PIPEWORK: To ensure accurate control, the temperature sensor should be mounted on the pipework as tightly as possible. It is essential that the sensing element is in direct contact with the pipework and that there is no insulation between it and the pipework. The temperature sensor can be fixed to the pipework using foil tape.

IN THERMAL POCKET: To ensure accurate control, the temperature sensor should be inserted into the thermal pocket. It is essential that the sensing element is inserted as far as possible. The temperature sensor can be fixed using the provided foil tape.

Mounting & Installation

Caution!

- Installation and connection should only be carried out by a qualified person.
- Only qualified electricians or authorised service staff are permitted to open the thermostat.
- If the thermostat is used in a way not specified by the manufacturer, its safety may be impaired.
- Prior to setting the thermostat, it is necessary to complete all required settings described in the section.







This thermostat can be mounted directly on the wall using the plate included.

Mounting & Installation (Continued)

- 1) The mounting height should be 1.5 metres above the floor level.
- 2) The place of installation should be chosen so that the sensor can measure the temperature as accurately as possible.

Choose the mounting location to prevent direct exposure to sunlight or other heating / cooling sources when mounted.

- 3) Fix the mounting plate directly to the wall with the screws provided.
- 4) Attach the thermostat to the mounting plate.
- 5) Lower the flap at the front of the thermostat. There is a battery compartment located below the buttons. Apply downward pressure to remove the cover.
- 6) Insert the 2 x AA batteries and the thermostat will turn ON. Close the battery compartment.






RF1A-OT Wireless Receiver
Installation Instructions

Specifications & Wiring

Power supply:	200 - 240Vac 50-60Hz
Contact rating:	250 Vac 10(3)A
Ambient temperature:	0 ... 45°C
Automatic action:	Type 1.C.Q
Appliance classes:	Class II appliance <input type="checkbox"/>
Pollution degree:	Pollution degree2
IP Rating:	IP20
Rated Impulse Voltage:	Resistance to voltage surge 2500V as per EN 60730

Internal wiring diagram for RF1A-OT



* If mains voltage output is required, terminals L & 2 must be electrically linked.







Important: Do not connect Mains Voltage to OpenTherm® terminals.

Mounting & Installation

- 1) The RF1A-OT receiver should be wall mounted in an area within 20 metres distance of the wireless thermostat. It is important that the receiver is mounted more than 300mm away from metal objects as this will affect communication with the thermostat.

The receiver should be installed at least 1 metre from any electronic devices such as radio, TV, microwave or wireless network adaptor.


- 2) Slacken the fastening screw on the bottom of the receiver with a philips screwdriver. The receiver is hinged and can be opened 180 degrees.
- 3) Screw the receiver to the wall with the screws provided.
- 4) Remove the protective cover on the terminal block.
- 5) Insert wires into terminal block in accordance with the wiring diagram.
- 6) Close the cover and tighten the fastening screw.






RFRP-HW-OT Cylinder Thermostat
Operating Instructions

LCD Symbol Description



Button Description



Automatic mode



Set Date / Time



Set point increase



Manual mode



Holiday mode



Set point decrease



Off mode



Copy function



Confirm button



Program mode



Boost mode



Reset button

Resetting the thermostat

Press the  button on the side of the thermostat.

'rst no' will appear on the screen.

Press the  button.

'rst yes' will appear on the screen.

Press the  button to reset the thermostat.

Keypad lock and unlock



OFF

To lock the keypad, press and hold the  and  buttons for 10 seconds.

 will appear on the screen. The keypad is now locked.

To unlock the keypad, press and hold the  and  buttons for 10 seconds.

 will disappear from the screen. The keypad is now unlocked.

Setting the date, time and programming mode

Press the  button once, the year will begin flashing.

Press the  or  buttons to adjust the year. Press .

Press the  or  buttons to adjust the month. Press .

Press the  or  buttons to adjust the day. Press .

Press the  or  buttons to adjust the hour. Press .

Press the  or  buttons to adjust the minute. Press .

Press the  or  buttons to adjust from 5/2d to 7d or 24h mode.

Press the  or  buttons to turn DST (Day Light Saving time) ON or OFF.

Press the  button or wait 5 seconds and the thermostat will return to normal operation.

Factory Program Setting



5/2d

5/2 Day						
	P1	P2	P3	P4	P5	P6
Mon-Fri	06:30	08:00	12:00	14:00	17:30	19:00
	ON	OFF	OFF	OFF	ON	OFF
Sat-Sun	08:00	10:00	12:00	14:00	17:30	19:00
	ON	OFF	OFF	OFF	ON	OFF

7 Day						
	P1	P2	P3	P4	P5	P6
Mon-Fri	06:30	08:00	12:00	14:00	17:30	19:00
	ON	OFF	OFF	OFF	ON	OFF
Sat-Sun	08:00	10:00	12:00	14:00	17:30	19:00
	ON	OFF	OFF	OFF	ON	OFF

24 Hour						
	P1	P2	P3	P4	P5	P6
Everyday	06:30	08:00	12:00	14:00	17:30	19:00
	ON	OFF	OFF	OFF	ON	OFF

Programming Modes

The RFRP-HW-OT Cylinder Thermostat has the following programming modes available:

5/2 Day mode Programming Monday to Friday as one block and Saturday and Sunday as a 2nd block.

Each block can have 6 different times and a status of ON or OFF.

7 Day mode Programming all 7 days individually with different times and temperatures.

24 Hour mode Programming all 7 days as one block with the same times.

If 7d mode is selected, you can program each day of the week with 6 individual times.

If 24H mode is selected, you can program each day of the week with the same 6 times.

Adjust the program setting in 5/2 Day mode

Press the  button once.

Programming for Monday to Friday is now selected.

Press the  or  buttons to adjust the P1 time.

Press .

Press the  or  buttons to select ON or OFF.

Press .

Repeat this process to adjust P2 to P6 times.

Press .

Programming for Saturday to Sunday is now selected.

Press the  or  buttons to adjust the P1 time.

Press .

Press the  or  buttons to select ON or OFF.

Press .

Repeat this process to adjust P2 to P6 times.

Press the  button to return to automatic mode.

While in PROG Mode pressing the  button will jump from P1 - P2 etc without changing the time.

While in PROG Mode pressing the  button will jump to the next day (block of days).

Copy Function

Copy function may only be used if the thermostat is in the 7d mode.

Set the times for the day that you wish to copy from in PROG mode.

When still on the day press the  button.

The day of the week that you have selected will be shown with 'COPY' below it.

The next day will begin to flash on the top of the screen.

Press the  button to copy the times and temperatures to that day.

Press the  button to skip a day.

You can copy to multiple days using the  button.

Press the  button when copying has been completed.

Permanent Override

Press the  button to enter the manual mode (Permanent Override), 'MAN' will appear on the screen.

Press the  or  buttons to adjust the temperature setpoint.

Press  or after 5 seconds the thermostat will operate in this permanent override.

To cancel permanent override, press the  button and then press the  button to return to the automatic mode.

Boost Function

The thermostat can be boosted for 1, 2 or 3 hours while the thermostat is operating in all modes except for holiday mode.

Press the  button 1, 2 or 3 times, the time that the boost will be activated to will flash on the screen.

If you do not press any other button the boost will activate to the temperature displayed on the screen after 5 seconds.

Press the  button or wait for 5 seconds for the boost to activate.


'**BOOST TO**' will now be displayed on the screen with the time that it is activated to displayed above this text.

Press the  button again to deactivate the boost.


Holiday Function


This will switch your heating system off between the start and end times you select .

Press the  button, 'HOLIDAY FROM' will appear on screen.

Press the  or  buttons to adjust the year. Press  .


Press the  or  buttons to adjust the month. Press  .


Press the  or  buttons to adjust the day. Press  .

Press the  or  buttons to adjust the hour. Press  .

'HOLIDAY TO' will appear on screen.

Press the  or  buttons to adjust the day. Press  .

Press the  or  buttons to adjust the month. Press  .

Press the  or  buttons to adjust the year. Press  .

Press the  or  buttons to adjust the hour. Press  .

The thermostat will now return to the mode it was in before the Holiday settings were entered. To cancel Holiday mode, press the  button.

Backlight mode selection AUTO

There are two settings for selection. The factory default setting is AUTO.

OFF The backlight is permanently OFF.

AUTO On pressing any button the backlight stays on for 5 seconds.

To adjust the backlight setting, lower the cover on the front of the unit.

Press the  button for 5 seconds.

Press either the  or  buttons to select the OFF or AUTO mode.

Press the  button.

Battery low warning

When the batteries are almost empty, the  symbol will appear on the screen.

The batteries must now be replaced or the unit will shut down.

Replacing the batteries


Lower the flap at the front of the thermostat.

There is a battery compartment located below the buttons.

Apply downward pressure to remove the cover.

Insert the 2 x AA batteries and the thermostat will turn ON.

Close the battery compartment.



Installer menu

To access the installer menu, you must hold  and  for 5 seconds.

When in the installer menu, press ,  and  to navigate and select.

Use ,  or  to go back a step.

P0 1: Mode (Normal)

P0 3: Hysteresis (differential)

P0 4: Calibration

P0 5: Frost Protection

P0 6: Exit

Installer menu **OpenTherm®** Instructions

P0 7: OpenTherm® Information

Exit

PO 1 Operating Mode (Normal)

Nor (Normal Mode)

When the thermostat is in Normal mode, the thermostat will try to reach the target temperature after the program changes.

Example: P1 on the thermostat is for 06:30am with a status of ON. The thermostat will start heating the hot water to the target temperature until the next programmed OFF time.

PO 3 Hysteresis HON and HOFF

This menu allows the installer to change the switching differential of the thermostat when the temperature is rising and falling.

HON is the fall in temperature – Default – 5.0°C. This will allow a fall of 5°C from the setpoint before the thermostat turns ON again.

HOFF is the rise in temperature – Default – 0.0°C. This will allow the temperature to rise 0°C above its setpoint.

PO 4 Calibrate the thermostat

This menu allows the installer to re-calibrate the thermostat. The current temperature will be displayed on the screen and can be adjusted by pressing the  or  buttons .

PO 5 Frost Protection 5°C

This menu allows the installer to activate or de-activate frost protection. When frost protection is activated the thermostat will switch on the boiler when the temperature drops below 5°C.

Exit

This menu allows the installer to return to the main interface.

It is also possible to exit the installer menu by pressing  ,  or  whilst in the installer menu.

PO 7 OpenTherm® Information

This menu allows the installer to view information received from the OpenTherm® boiler. It may take a few seconds to load information relating to each parameter. The information that can be shown from the boiler is outlined in the table below.

Displayed on screen	Description	Remark
tSEt	Target water temp	
tFLO	Outlet water temp	
trEt	Return water temp	
tdH	DHW temperature	This is only visible if DHOP is ON (P08 OT Installer menu)
tFLU	Flue gas temperature	Dependent on boiler
tESt	Outdoor temperature	Dependent on boiler
nOdU	Modulation percentage	
FLOr	Water flow	This is only visible if DHOP is ON (P08 OT Installer menu)
PrES	Water pressure	Dependent on boiler

Exit

This menu allows the installer to return to the main interface.

It is also possible to exit the installer menu by pressing  ,  or  whilst in the installer menu.

Controlling an OpenTherm® Boiler with multiple CP4-OT / CP4-HW-OT

It is possible to have 6 CP4-OT/ CP4-HW-OT controlling 1 OpenTherm® boiler. To do this it is necessary to make one of the RF1A-OT receivers into a Hub Receiver. This Hub Receiver will receive data from all of the RFRP-OT and RFRP-HW-OT thermostats and relay this information to the boiler via OpenTherm®.

Note: The Hub Receiver should have a wired OpenTherm® connection to the boiler.

Making your RF1A-OT receiver into a Hub Receiver

1. Press the Reset  button on the receiver that you wish to make the Hub Receiver – Red and Green lights are both solid.
2. Immediately press and hold the  and  buttons for 5 seconds, the red light will start blinking.
3. Press the  button and the Green light will be solid – this is now the hub receiver.
4. Press the  button to exit to the normal interface.

Identifying if a receiver is a Hub Receiver

1. Press the  button.
2. The Hub receiver will flash Green and Red.
3. The Normal receiver will just flash Red.
4. To exit to main interface press the  button.

Pairing the RF1A-OT receivers together

1. Press the  button on the Hub receiver. Red and Green lights will begin to flash.
2. Press the  button on the next receiver to be paired. The Red light will flash 3 times and then stop.
3. Repeat this process to pair more, up to a maximum of 6 receivers.

Once all units have been paired, allow time for the receivers to begin to communicate and receive OpenTherm® information from the boiler. This may take approximately 2 – 5 minutes.

Controlling an OpenTherm® Boiler with multiple CP4-OT / CP4-HW-OT (Continued)

If the installer menu is only showing P01 - P03 then OpenTherm® is not communicating. Check pairing and OpenTherm® wiring.

You will see the red light flash on the Hub receiver and see a corresponding flash on the other receivers paired to the Hub Receiver when they are sharing information.

You may need to pair the receivers to the thermostats again.

If so, please refer to page 48.

You can tell if your thermostat is receiving OpenTherm® information from the boiler by entering the installer menu of the thermostat (Hold  and  buttons for 10 Seconds) and go to P07 - Info.

If the installer menu is only showing P01 – P05, the thermostat and/or receiver has not been successfully paired.

Disconnecting the RF1A-OT receiver from Thermostats & other Receivers

1. Press  on the Receiver – the red light will flash (red and green light if using a hub receiver)
2. Press and hold  for 10 seconds and the receiver will then stop flashing.
3. The RF connection is now cleared.

System architecture

Example A 1 no. Thermostat controlling OT Boiler



RFRP-HW-OT Thermostat




RF1A-OT Receiver



OpenTherm® Boiler

Example B 3 no. Thermostats controlling OT Boiler >>

Note: A maximum of 6 thermostats can be used in the system.





RF1A-OT Wireless Receiver
Operating Instructions

Button / LED Description



Manual



Manual override

■ Reset button

Press to reset the receiver



Wireless connect:

Once voltage has been applied this button may be pressed to initialise the pairing process with the wireless thermostat. Once pressed the red and green LED will begin to flash.

LED Description

OT Connection Normal Operation	Green LED	Red LED
RF1A-OT ON	ON	OFF - will flash when communicating via RF
RF1A-OT OFF	OFF	ON - will flash when communicating via RF

OT Communication Error	Green LED	Red LED
RF1A-OT ON	Constant Flash	OFF
RF1A-OT OFF	Constant Flash	ON

RF Communication Error	Green LED	Red LED
RF1A-OT ON	ON	Constant Flash
RF1A-OT OFF	OFF	Constant Flash

Summary	Green LED	Red LED
RF Communication Error	OFF or ON	Constant Flash
OT Communication Error	Constant Flash	OFF or ON
Normal Operation RF1A ON	ON	OFF or Flashing
Normal Operation RF1A OFF	OFF	ON or Flashing

To connect the RFRP-HW-OT thermostat to an RF1A-OT receiver

Please note, If you are installing a CP4-HW-OT the RFRP-HW-OT thermostat & the RF1A-OT receiver will have a pre-established RF connection so it is not necessary to carry out the RF connection process below.

On the RF1A-OT receiver:

Press the  button.

The red light will begin to flash.

On the RFRP-HW-OT thermostat:

Press the  button.

The thermostat will show 'nOE' followed by '---'

Once an RF connection has been established the thermostat will show 'r01' on the LCD screen.

Press the  button to finish the process.

The thermostat is now connected to the RF1A-OT receiver.

To disconnect the RFRP-HW-OT thermostat from an RF1A-OT receiver

This can be done from either the thermostat or the receiver.

On the RFRP-HW-OT thermostat:

Press the  button. The thermostat will begin to search through the RF channels.

Press and hold the  button for 10 seconds. 'Adr' will appear on the screen of the thermostat.

Press the  button twice to complete the unpairing process. The thermostat RFRP-HW-OT is now disconnected from the receiver RF1A-OT.

On the RF1A-OT receiver:

Press the  button, the red light will flash.

If using as a hub receiver, the Red & Green lights will flash.

Press and hold connect for 10 seconds, the receiver will then stop flashing.

The RF connection is now cleared.

EPH Controls IE

technical@ephcontrols.com
www.ephcontrols.com/contact-us
T +353 21 471 8440



EPH Controls UK

technical@ephcontrols.co.uk
www.ephcontrols.co.uk/contact-us
T +44 1933 322 072

