



## Smoke & Heat Alarms

**POWER IS OK** Red LED flashes  every minute followed by a single beep  after 10 seconds if the battery power is weak

**FULL ALARM** Red LED flashes  twice every second plus a series of three beeps  every 4 seconds

**EVACUATE THE PROPERTY IMMEDIATELY AND CALL THE EMERGENCY SERVICES!**

**ALARM SILENCE** Red LED flashes  once every 10 seconds

**TEST** Red LED flashes  twice every second, plus a series of three beeps 

**GENERAL FAULT** Double beep  every minute

**TEST BUTTON JAMMED** Single beep  every 11 seconds



### RADIO PATTERNS LIGHTS

**POWER IS OK** Green LED flashes  once every minute

**RADIO SIGNAL** Long red LED  means that the pattern is either transmitting or receiving radio signals

**PAIRING** Green LED flashes  every second when it is pairing mode

**ALWAYS** read the **ENTIRE** handbook and keep it in a safe place!  
**ALWAYS** make sure you understand the lights and sounds.